

Prolo Ring Gesture Cheat Sheet (Firmware 1.0.5)

Prolo features four control **modes**: Cursor, Touch, Navigation and Air. The modes and gesture sets are selected/toggled using Modstrip.

Quick Mode Reference

| Mode | How to Enter | Default Use | Additional Features |
|------------|-----------------------------|------------------------|----------------------------------|
| Cursor | Swipe Left on Modstrip | Mouse & cursor control | Mod Long Hold Options |
| Navigation | Swipe Right on Modstrip | In-App navigation | Desktop/XR Style vs Mobile Style |
| Touch | Swipe Right + Hold Modstrip | Media control | Hold Modstrip to use ModTouch |
| Air | Swipe Left + Hold Modstrip | Motion control | Hold Trackpad to use AirTouch |

Cursor Mode

Everyday control for cursor and scrolling.

| | |
|---|---|
| Move on Trackpad | Move cursor |
| Single Tap | Left click |
| Edge Scroll | Instant vertical scroll |
| Mod Long Hold | Start scroll/pan (continuous). Double taps to exit |
| Move + Mod touch (add Mod while moving) | Cursor movement speed (2x speed by default) |
| Mod Hold + Trackpad Move | Click-and-drag. Release both fingers to stop dragging |
| Bottom Left Corner Hot Key: Long Hold | Middle click |
| Bottom Right Corner Hot Key: Long Hold | Right click |
| Bottom Left Corner Hot Key: Double Click | Snap cursor to left |
| Bottom Right Corner Hot Key: Double Click | Snap cursor to right |
| Dual-Finger Tap Hot Key: Mod + Track | Middle key press (Latched, single tap to cancel) |
| Dual-Finger Tap Hot Key: Track + Track | Right key press (Latched, single tap to cancel) |
| Trackpad Hold + Single Air Tap | Snap cursor to left |
| Trackpad Hold + Double Air Tap | Snap cursor to right |

Navigation Mode

In-app **navigation** for presentations, browsing and e-reading. Two styles to choose from.

To toggle between Desktop/XR style and Mobile Style, use 7xTap + Press Hold Modstrip. Requires Re-Pair after changing Styles.

| | Desktop/XR Style (Default) | Mobile Style (Overlay) |
|--------------------------|-------------------------------|---------------------------------|
| Swipe Up/Down (+Hold) | Up/Down arrow (continuous) | Mobile swipe up/down |
| Swipe Right/Left (+Hold) | Right/Left arrow (continuous) | Mobile swipe right/left |
| Tap | Enter | Mobile Single Tap |
| Double Tap | Consumer Back (XR Glasses) | Mobile Double Tap (Tiktok Like) |
| Triple Tap | Consumer Home (XR Glasses) | Mobile Double Tap (Tiktok Like) |
| Dual-Finger Pinch In | Zoom out (Ctrl -) | N/A |

| | | |
|-----------------------|------------------|-----|
| Dual-Finger Pinch Out | Zoom in (Ctrl =) | N/A |
|-----------------------|------------------|-----|

Note: Customizable gestures are available only with Pro Edition.

Touch Mode

Standard Gestures — Quick control for media.

| | |
|---------------------|----------------------------|
| Swipe Up (+Hold) | Volume up / Camera Shutter |
| Swipe Down (+Hold) | Volume down |
| Swipe Right (+Hold) | Next track |
| Swipe Left (+Hold) | Previous track |
| Tap | Play / Pause |
| Double Tap | Mute |
| Triple Tap | Customizable* |

ModTouch Gestures — More media control and customizations by holding Modstrip.

| | |
|--|---------------|
| Mod Hold + Swipe Right | Fast Forward |
| Mod Hold + Swipe Left | Rewind |
| Mod Hold + Swipe Up / Down | Customizable* |
| Mod Hold + Tap / Double Tap / Triple Tap | Customizable* |

Air Mode

Standard Gestures — Control without touching any surface.

| | |
|---------------------|---------------|
| Swipe Left / Right | Customizable* |
| Single / Double Tap | Customizable* |

AirTouch Gestures — Hold the Trackpad for more controls in Air Mode.

| | |
|-------------------------------------|---------------|
| Trackpad Hold + Swipe Left / Right | Customizable* |
| Trackpad Hold + Single / Double Tap | Customizable* |

System & Mode Actions

| | |
|---|--|
| Swipe Left on Modstrip | Enter Cursor Mode |
| Swipe Right on Modstrip | Enter Navigation Mode |
| Swipe Right & Hold on Modstrip | Enter Touch Mode |
| Swipe Left & Hold on Modstrip | Enter Air Mode |
| 1x Tap (Modstrip) + Press Hold (Modstrip) | Connect / Switch / Unlock |
| 2x Tap (Modstrip) + Press Hold (Modstrip) | Enter Pairing to Add a New Device |
| 3x Tap (Modstrip) + Press Hold (Modstrip) | Toggle Device Status ←→ App Status |
| 4x Tap (Modstrip) + Press Hold (Modstrip) | Shutdown (Requires Charging to Turn On) |
| 5x Tap (Modstrip) + Press Hold (Modstrip) | Reset to Factory Default |
| 6x Tap (Modstrip) + Press & Hold (Modstrip) | Enter OTA Mode for Firmware Update |
| 7x Tap (Modstrip) + Press & Hold (Modstrip) | Toggle Navigation Style (Desktop/XR vs Mobile) |
| Palm Hold | Lock (Requires Unlock Gesture or Charging to Unlock) |